





- 2 Ground the universal mounting bracket to junction box and transformer wire.
- Connect the black and white wires of transformer to the hot and neutral wires in Jbox.
- 4 Insert transformer into Jbox.
- 5 Connect secondary low voltage wires of transformer to universal mounting bracket connector wires.
- Position universal mounting bracket toward Jbox and secure universal mounting bracket directly to Jbox using screws from accesory bag.
- 7 Insert Lamp
- Place the canopy cover over the universal mounting bracket and screw on the Glass with threaded collar onto universal mounting bracket.
- 9 Evenly screw on glass till SNUG.
  DO NOT OVERTIGHTEN

## **SAVE THIS INSTRUCTIONS**

